# LECTIX

# DCC brake module

#### 1 Overview

- Module equivalent to the BM1 module ref 22600 from Lenz.
- Allows the gradual stop and restart of trains running in a DCC environment.
- Maximum current of 1A
- ABC Breaking module for DCC only compatible with a few decoders (see section 3)



# 2 Applications

- Automatic stop of a convoy at the foot of a signal.
- push-pull operation.
- Cantons.
- Automatic stop when the railway switch is not properly set.
- Automatic stop at the station.

## 3 Compatibility

**Warning:** this module only works in digital mode and is only compatible with decoders that support ABC technology. The table 1 shows a non-exhaustive list of decoders supporting ABC technology.

| Brand | Compatible decoder  | Manufacturer reference   |
|-------|---------------------|--------------------------|
| Lenz  | Gold maxi           | 10440                    |
|       | GOLD+ NEM652        | 10433-01                 |
|       | GOLD+ mini NEM651   | 10411-01                 |
|       | GOLD+ mini wired    | 10410-01                 |
|       | Silver+ NEM652      | 10331-01                 |
|       | Silver+ direct      | 10330-01                 |
|       | Silver+ 21          | 10321-01                 |
|       | Silver+ Plux12      | 10312-01                 |
|       | Silver+ mini NEM651 | 10311-01 / 10311-02      |
|       | Silver+ mini wired  | 10310-01                 |
|       | Standard+ V2        | 10231-02                 |
| ESU   | LokPilot V4 / V5    | Every LokPilot V4 and V5 |
|       | LokSound V4 / V5    | Every LokSound V4 and V5 |



| Brand | Compatible decoder       | Manufacturer reference                |
|-------|--------------------------|---------------------------------------|
|       |                          | MX620, MX620N, MX620R, MX620F         |
|       | Miniature decoders       | MX618N18,MX621, MX621N, MX621R        |
|       |                          | MX621, FMX622, MX622R, MX622F, MX622N |
| zimo  |                          | MX63, MX63R, MX63F, MX63T             |
|       | HO decoders              | MX623, MX623R, MX623F, MX623P12       |
|       |                          | MX630, MX630R, MX630F, MX630P16       |
|       | Thin HO decoders         | MX64, MX64R, MX64F, MX64T             |
|       |                          | MX64H, MX64HR, MX64HF, MX64V          |
|       |                          | MX631, MX631R, MX631F, MX631D, MX631C |
|       | High power HO decoders   | MX632, MX632R, MX632D, MX632C, MX632V |
|       |                          | MX632W, MX632VD, MX632WD              |
|       |                          | MX633, MX633R, MX633F, MX633P22       |
|       | Ministure cound decoders | MX648, MX648R, MX648F, MX648P16       |
|       | Miniature sound decoders | MX646, MX646R, MX646F, MX646N, MX646L |
|       | HO sound decoders        | MX645, MX645R, MX645F, MX645P16       |
|       | The sound decoders       | MX645P22, MX644D, MX644C              |

Table 1 - Compatible decoders

## 4 Technical specifications

| Specification                 | Unit | Value        |
|-------------------------------|------|--------------|
| Maximum continuous current    | A    | 1            |
| Maximum peak current (8.3 ms) | A    | 30           |
| Dimensions                    | mm   | 25 * 20 * 13 |
| Weight                        | g    | 3.1          |

Table 2 - Specifications

#### 5 Usage

By generating an asymmetry in the DCC signal, this module allows compatible decoders to detect areas of slowdown or shutdown and react accordingly.

There are two steps to setting up this module: installation and wiring of the module and configuration of the decoder(s).

#### 5.1 Installation and wiring of the module

Note: For optimal and safe operation, this module must be wired with a minimum cross-sectional area of 0.2 mm<sup>2</sup>.

The module must be wired as shown in the figure 1. The switch is optional. It allows the module to be shunted to manually restart the stopped train.

• When the switch is open, or there is simply no switch, a signal will be emitted on the



Figure 1 – Wiring diagram for a stop zone controlled by a switch.

right rail of the stop zone, and any machine with a compatible and configured decoder will perform a stop procedure.

• When the switch is closed, no signal will be transmitted at the stop area, so no train will stop in the area. If a train was stopped in the stop area, it will restart gradually.

**Note:** The switch can be replaced by a relay, a limit switch, or by any other system with a breaking capacity of at least 1A.

#### 5.2 Decoder configuration

To detect the ABC signal emitted by this module, the decoders must be configured accordingly. The table eftab:cv shows the CVs used to enable or modify the decoder's behaviour towards the ABC signal.

In any case, you will need to activate the ABC function of the decoder so that your trains can react to the signal emitted by this module.

| Brand | CV  | bit | Function  |  |
|-------|-----|-----|---|--|
| Lenz  | 51  | 0   | Constant braking distance activated                       |  |
|       |     | 1   | ABC activated   |  |
|       |     | 2   | ABC direction-dependency deactivated                      |  |
|       |     | 3   | Activate push-pull operation without intermediate stop    |  |
|       |     | 4   | Activate push-pull operation with intermediate stop       |  |
|       | 52  | -   | Braking distance with activated constant braking distance |  |
|       | 54  | -   | Stopping time in push-pull operation, 1 to 256 sec        |  |
| ESU   | 27  | 0   | ABC braking, voltage higher on the right hand side        |  |
|       |     | 1   | ABC braking, voltage higher on the left hand side         |  |
|       | 134 | -   | ABC Detection threshold                                   |  |
|       | 254 | -   | Constant stopping distance                                |  |

| Brand | CV  | bit | Function   |
|-------|-----|-----|--|
| zimo  | 27  | 0   | Activation of the ABC in the conventional direction of motion. |
|       |     | 1   | Activation of ABC in reverse direction                         |
|       | 134 | -   | ABC Detection threshold  |
|       | 140 | 0   | Activation of the constant braking distance function           |
|       | 141 | -   | Constant braking distance                                      |
|       | 142 | -   | High-speed compensation of the ABC detection threshold         |

Table 3 – CV for ABC

Note: If the manoeuvre mode or the reduced run mode is activated, the decoder will ignore the ABC signals.

#### 6 Measures



Figure 2 – Dimensions of the module (all dimensions in mm).

## 7 Contact and support

For further information, please contact contact@lectix.fr.

## 8 **Revision History**

| Revision | Date     | Author(s) | Description                    |
|----------|----------|-----------|--------------------------------|
| 1.0.0    | 20.04.20 | TFC       | Creation of the document       |
| 1.0.1    | 23.04.21 | TFC       | Minor changes                  |
| 1.0.2    | 24.04.21 | TFC       | Update of the list of decoders |